



WHERE INDUSTRY TURNS FOR INNOVATIONSM

Chip Load = Feed Rate (inches per minute) / (RPM x number of flutes)

Chip Load Chart

TOOL DIAMETER	HARD WOOD	SOFTWOOD/ PLYWOOD	MDF/PARTICLE BOARD	HIGH PRESSURE LAMINATE	PHENOLIC/ PAPERSTONE
1/8"	.003" - .005"	.004" - .006"	.004" - .007"	.003" - .005"	
1/4"	.009" - .011"	.009" - .013"	.013" - .016"	.009" - .012"	.004" - .006"
3/8"	.015" - .018"	.017" - .020"	.020" - .023"	.015" - .018"	.006" - .008"
1/2" & up	.019" - .021"	.021" - .023"	.025" - .027"	.023" - .025"	.010" - .012"

TOOL DIAMETER	HARD PLASTIC	SOFT PLASTIC	SOLID SURFACE	ACRYLIC	ALUMINUM
1/8"	.002" - .004"	.003" - .006"	.002" - .004"	.003" - .005"	.003" - .004"
1/4"	.006" - .009"	.007" - .010"	.006" - .009"	.008" - .010"	.005" - .007"
3/8"	.008" - .010"	.010" - .012"	.008" - .010"	.010" - .012"	.006" - .008"
1/2" & up	.010" - .012"	.012" - .016"	.010" - .012"	.012" - .015"	.008" - .010"

RPM Formulas

Feed Rate = RPM x number of flutes x chip load
RPM = Feed Rate / (number of flutes x chip load)
Metric Conversion: Divide inches per minute by 39.374
(ex. 300 inches per minute divided by 39.374 = 7.62 meters per minute)

Tooling 3/8" and smaller in Ø use **18,000 RPM**
Tooling Larger than 3/8" in Ø use **16,000 RPM**



Scan QR Code To Learn More On RPM Formulas



5605 East Jelinek Avenue • Schofield, WI 54476
800-355-7708 • fax 715-355-7353

